



## Instrukcja obsługi Welltec FDHNNH

### Montaż

**1.** Otwórz i wyjmij tylny panel urządzenia.



**2.** (Opcjonalnie) Umieść filtr węglowy w ramce tylnego panelu.



**3.** Umieść filtr HEPA w ramce tylnego panelu i zamontuj tylni panel w urządzeniu.



### Czyszczenie i konserwacja

Filtr należy czyścić raz w miesiącu, za pomocą odkurzacza (jedynie po stronie zewnętrznej, czyli przylegającej do filtra węglowego lub kratki tylnego panelu). Pod żadnym pozorem **NIE** wolno używać wody, ponieważ uszkodzi ona trwale filtr HEPA.

Podczas pracy osuszacza należy okresowo sprawdzać czy filtr HEPA pozostaje suchy. Nie wolno używać filtra HEPA gdy jest wilgotny. Jeśli filtr jest mokry należy go dokładnie wysuszyć przed ponownym użyciem. Uszkodzenia urządzenia spowodowane pracą z wilgotnym filtrem HEPA nie podlegają gwarancji.

Filtr należy okresowo kontrolować aby nie dopuścić do zbytniego zabrudzenia lub przebicia filtra. Powinien być wymieniany co 6-24 miesięcy w zależności od stopnia zużycia i zanieczyszczenia.

### Uwaga!

Po zamontowaniu filtra HEPA nieznacznie spada przepływ powietrza. Może to prowadzić do niewielkiego spadku wydajności osuszania i jest to proces normalny, nie stanowiący podstawy do reklamacji.



## Instruction manual Welltec FDHNN

### Setup

1. Open and remove the rear panel of the device.
2. (Optional) Place the carbon filter in the rear panel frame.
3. Place the HEPA filter in the rear panel frame and insert the rear panel into the device.



### Cleaning and maintenance

The filter should be cleaned once a month with a vacuum cleaner (only on the outside, adjacent to the carbon filter or rear panel grille). Under no circumstances should you use water as it will permanently damage the HEPA filter.

When operating the dehumidifier, periodically check that the HEPA filter remains dry. Do not use the HEPA filter while it is wet. If the filter is wet, dry it thoroughly before reusing it. **Damage to the device due to operation with a wet HEPA filter is not covered by the warranty.**

The filter should be checked periodically to prevent excessive dirt or puncture of the filter. It should be replaced every 6-24 months depending on the degree of wear and contamination.

### Warning!

After installing the HEPA filter, the air flow is slightly reduced. This can lead to a small decrease in dehumidification performance and it is a normal process, thus it cannot be used as a complaint.